








## HOW TO ADJUST THE Z POINT

1. Turn the machine ON and open the door by pressing this button .
2. Press the button .
3. Press again the button .
4. Enter the password 1234 and press  to confirm.
5. Keeping the door manually opened, put a Basic tag without the packaging on the carriage, roughly at the bottom of the mould, like shown in the following photo:



6. Carry on keeping the door manually opened and press the Z in the first left half of the screen.
- Wait until the plate is not inside and the tip will not be placed on the tag.
7. If it is the case in which the tip will press too much the tag (for example there are lines between one character and another) press the arrow pointing upwards and, holding down, pick up the tip until the is touched by the tip.
  8. If it is the case in which the tip will not touch almost the medal, press the arrow pointing down and holding down, bring down the tip until the tip touches the tag.
  9. Remove the tag and leave the door: it will close itself thanks to the spring.
  10. Save the position of the tip by pressing the button  and wait a moment.
  11. Switch the machine off. Wait 10 seconds and switch the machine ON.

**The process is now finished!**